GrainPro® Hermetic Bag Premium™



(ZIPPER)



Fold GrainPro Bag Hermetic Premium lengthwise and insert inside the outer bag.

NOTE: Refer to suggested outer bag dimensions below.



Unfold GrainPro Bag Hermetic Premium and fold extra plastic to prevent damage.



Pour the dry commodity until it reach the MAXIMUM FILL LINE.
Leave at least 10 cm of plastic for proper sealing.



Unroll and remove air by pressing down on the grains

OPTIONAL: Add oxygen absorber to immediately lower the oxygen level.


In case of pulses, oxygen absorbers are to be added (1 sachet per 50 kg commodity)



Press one end of the track and push slider from top end of the zipper. Move slider to the other end to seal.



Fold down the zipper twice for better sealing.




Close the outer bag by tying or sewing at 3cm distance from "zipped" inner liner.



Stick the 'No Hooks' label on the outer



After using, clean, dry and fold undamaged GrainPro Bag Hermetic Premium and save it for future use.







For more Information about hermetic storage systems, visit www.grainpro.com or email customercare@grainpro.com

MA4091CSD0122